Schmiertabelle Bohr / Stemmhämmer

Schmiertabelle Bom / Oten				**ODELL		Wartung		∍p <u>.</u>	
TOOPIU T	Wartung	Rep.	<u> </u>	MODELL		E20)	(100	Occl)	
MODELL	1Tube	1Tube	80	35NB	1Tu		<u>1T</u>	ube	
HR2000	1Tube	1Tube		(0500	TITU		11	ube_	
HR2010	1Tube	1Tube		(1800	1170		11	ube	
HR2410	1Tube	1Tube		<u> </u>		ibe	17	Tube	
HR2400	1Tube	1Tube_	H	M0810		ipe	1	Tube	
HR2430	1Tube	1Tube	H	M0810B		ube	1	Tube	
HR2440	1Tube	1Tube	H	M0810T		ube	1	Tube_	
HR2450	1Tube	1Tube		M1100C M1130C		ube		Tube	١
HR1600 HR1800	1Tube	1Tube	- 1841	M1140C	117	ube	· · · · · · · ·	Tube_	{
HR1820	1Tube	1Tube	<u> </u>	M1200	17	ube	·	Tube	1
HR2200	1Tube	1Tube	__\\\	1M1200B	1	Tube_		Tube	-
HR2510	1Tube	1Tube		1M1200K	11	Tube		<u>1Tube</u>	-{
HR3000C	1Tube_	2Tuben		HM1202C	2	Tuben	_	Tuben	
HR3550C	1Tube	2Tuber		HM1242C	$-\frac{1}{2}$	Tuben		Tuben	- L
HR3520	1Tube	2Tuber		HM1300	. 11	Tuben	<u> — — </u>	4Tuben	
HR3520B	1Tube	2Tuber		HM1303	1	Tuber	" +- -	4Tuben	_
HR3850	1Tube	2Tube		HM1303B		Tuber	<u></u>	4Tuber	_
HR3850B	1Tube	2Tube		HM1400		2Tuber	 +	4Tuber	
HR3850K	1Tube	2Tube	200	HM1304	3	2Tube		4Tubel	
HR4000C	1Tube	1Tube		HM1500		3Tube		4Tube	
HR4040C	1Tube	1Tub	2.6	HM1500B		3Tube		4Tube	
HR4500C	1Tube			HM1800		4Tub€	_		
HR5000	2Tube	_		8015D		Lagerf	ett '	Lagerfe 1/2Tu	he
HR5000K	2Tube			HR160D		1/2Tu		1/2Tu	
UB5001C [2] upen 121			<u></u> -{	BHR200SF		1/2TL		1/2Tu	
Pohr-/Stemmhämmer				BHR2009	SHE	1/2Tu	loe	11210	
Menge für Getriebefett									
			_		\ 	auui /			

Bestellnummer für Getriebefett P-08361 (Tube å 30gr) Getriebeöl (Nur für 8035NB) 181118-7 (Flasche 100cci)

Wartung: Menge bei normaler Wartung (Setrlebsanleitung beachten) Reparatur: Menge bei ausgewaschenem Getrlebegehäuse im Falle einer Reparatur

Bei allen Geräten ist ausschließlich Makita Getriebefelt zu benutzen (P-08361)

Bei Modell 8035NB ist Getriebeöl HD-Öl SAE20 (181118-7) nachzufüllen.

Bei Modell 8015D wird das Getriebe mit normalem Lagerfett geschmiert.

